

How to protect your CNC system

1. We may need to connect one workstation with CNC machine via **RS232 connection**. (download code)
2. We need to have **serial port sharer** for multiple CNC to connect with workstation. (workstation just have one RS232 to connect and we don't need to change RS232 connection manually)
3. We need to have **GROUND isolated feature** between workstation and every CNC machine. (each CNC may have big ground bounce to burn your system)
4. We need serial port sharer with **GROUND isolated feature** in each RS232 connection. (S232io box can have **double GROUND isolated barrier** between master and slave RS232 serial port to protect your system)

